


INSTRUCTIONS ON HOW TO REBUILD MINI-SERIES PRESSES

To **Disassemble** the unit use the following steps:

- 1. Remove Piston Nut
- 2. Slide Upper Body and Piston off the rods
- 3. Remove Piston from Upper Body
- 4. Replace Rod Seals, Piston Seal and Piston Wear Ring as required. Put light coating of petroleum jelly on all Seals and Wear Ring
- 5. Put light coating of petroleum jelly on all Rods and Cylinder Bore.

To <u>Assemble</u> the unit use above steps 1, 2 & 3 in reverse order to complete installation.



The minimum supply air line should be nominal 3/8" I.D. hose or tubing with 50 to 100 PSI air pressure.